

Maintenance

1. Clean the fused silica glass if the image is fuzzy (it could be cleaned by some ash or some old O-rings).
2. Replace the square pad with round hole for silica glass every 12-15 days (The replaced pad could be used to clean above mentioned silica glass)
3. Replace the round pad for sample sending device every 12-15 days
4. Spread grease oil on the sample sending device every 6 months.